

Changing Run Times in Standard Mode

If you need to edit the **Run Time** for each station (zone) in **Standard Mode**, review the steps below to access this feature. The following fields are also available:

Time and Frequency

Program Name

Choose the program name and program type.

Start Times

Choose the water days and up to six start times.

Run Times

Choose the number of minutes each zone will run for each start time. Run times must be from 1 min to 23 hrs and 59 mins.

Schedule Adjustment

Choose how to adjust the watering time based on your weather triggers.

Monthly Adjustment

Monthly adjustments can be made using a chart as well. This will allow the run times set in a program to change by month as a global percentage (e.g.; June 80%, July 90%, August 100%).

Edit Run Times

1. Sign in to your [Hydrawise account](#). [1]
2. Click on **Zones** at the bottom of the app or **Zones and Programs** on a web browser from the home dashboard.
3. Select **Programs**.
4. Select the (⊖) icon for the program that requires the change.
5. Select **Next 2X** in the zone details.
6. Click on **Select All Zones** to appear in the right selection bar.
7. Enter the watering **Run Time** in minutes for each zone.
8. Select **Done**, then **Ok** to save.