



# Why are my Flow Readings So High?

There are two things to consider when this occurs:

- 1) Check that you have the right flow meter installed and selected via the flow meter set up on the software. If you have a 3/4" but selected 1", the reading can appear up to 10x higher than it should be.
- 2) Carefully follow the instructions in our wiring guide.

□

Ensure that the common wire is connected to the sensor common and not the common for the valve, as this will cause massive spikes in readings. **DO NOT USE THE RED WIRE, must cap off.**

□

□

For a more detailed look at our flow meter installation guide, click [here](#) [1].