



How do I set global default watering triggers?

Contractors now have an option to set default watering triggers for new customers in the customer wide settings.

When a new controller is created (Contractor Portal only), the controller will automatically get the contractor's default Watering Triggers. If you want to have different settings for a specific controller, then they can be changed in the normal way.

Please view the steps to access this feature:

1. Click on the "**Manager**" icon on the upper right hand side, then "**Customer Wide Settings.**"
2. Click on the "**Default watering triggers**".

NOTE: The trigger can be turned OFF completely by using the slide bar option within this water trigger section.

□

It is also possible to re-apply Watering Triggers to one or all of your customers if they have changed from the settings in the Contractor Portal:

Please view the steps to access this feature:

1. Click on "**Re-Apply Settings**".
2. Choose all controllers or selected controllers to update the changes and select "**OK**".

□

